



SEEDS OF HOPE

INTERNATIONAL PARTNERSHIPS


Corrugated Sand Filter

FORM FILL BLOCKS

MIX DRY:

20 PARTS SAND
1 PART CONCRETE

ADD ENOUGH WATER
TO CREATE WET MIXTURE.
TOO LITTLE WATER WILL
PRODUCE WEAK, CRUMBLY
BLOCKS.



FILL MOLD WITH MIXTURE AND COMPACT COMPLETELY
BY TAMPING FIRMLY WITH A FLAT SURFACE.
FLUSH MATERIAL TO TOP OF FORM.
AFTER WATER DRAINS OFF, REMOVE MATERIAL FROM
CENTER OF BLOCK LEAVING 2" THICK WALLS.
MOVE TO FINAL LOCATION BEFORE REMOVING FORM.
ALLOW TO BAKE IN SUN 1-2 DAYS.